7FA Series





AIRBEST



Features

- Straight through design, one-touch fitting, with bracket, easy to mount
- Small size and light weight
- Filter elements could be replaced
- Suitable for vacuum and positive pressure systems with light or medium pollution level

① Series ② Filter area



How to order

ZFA 5 4 B

ZFA	5 - Filter area 790mm²	4 - φ4 hose	B - Default, with bracket
	7 - Filter area 1,280mm²	6 - ф6 hose	
		8 - φ8 hose	
		10 - φ10 hose	
		12 - φ12 hose	

Selection


Model/Hose diameter 4 - ф4hose	6 - ¢6hose	8 - φ8hose	10 - ф10hose	12 - ф12hose
ZFA54B	ZFA56B	-	-	-
-	ZFA76B	ZFA788	ZFA710B	ZFA712B

Technical parameters


Model	Hose diameter mm	Fluid	Rated operating pressure range MPa	Max. pressure resistance MPa	Positive pressure flow NL/min	Vacuum flow NL/min	Removal efficiency µm	Operating temperature °C	Weight g
ZFA54B	ф4	Air,Nitrogen	-0.1~0.8	1.0	40	10	5	0~60	14
ZFA56B	ф6	Air,Nitrogen	-0.1~0.8	1.0	130	75	5	0~60	13
ZFA76B	ф6	Air,Nitrogen	-0.1~0.8	1.0	140	80	5	0~60	24
ZFA78B	ф8	Air,Nitrogen	-0.1~0.8	1.0	280	110	5	0~60	24
ZFA710B	ф10	Air,Nitrogen	-0.1~0.8	1.0	320	120	5	0~60	30
ZFA712B	ф12	Air.Nitrogen	-0.1~0.8	1.0	370	140	5	0~60	31

O Note: Positive pressure flow is tested at air supply pressure 0.1Mpa

Max. operating pressure and temperature



Application diagram




Dimensions (mm)

ZFA7□B



Model/Size	L	LI	D	d
ZFA548	55.5	8	4	13




Model/Size	L	LT	D	d
ZFA76B	67	10.5	6	15.5
ZFA78B	69.5	12	8	16
ZFA710B	78.5	17	10	19.5
ZFA7128	78.5	17	12	21

AIRBEST

Universal Vacuum Filter

Structural diagram



NO.	Item	Material	Q'ty
1	Housing	PC	1
2	Rear cap	PBT	1
3	Filter element	PE	1
4	0-ring	NBR	2
5	Front cap	PBT	1
6	One-touch fitting	-	2
7	Bracket	PBT	1

Repair kits



Item	Model	Dimension	Applicable vacuum filter
Tool	ZFA5-SP	-	ZFA54, 56
	ZFA7-SP		ZFA76, 78, 710, 712
Filter element	ZFA5-FE	8×12×L20	ZFA54, 56
	ZFA7-FE	12×16×L25	ZFA76, 78, 710, 712

Note: The minimum packing quantity of filter element is 10pcs/bag.

Filter element replacement

- 1. Stop supplying air and reduce the pressure in the vacuum filter to
- atmospheric pressure

 2. Put tool on the front cap and turn it 90° anti-clockwise
- Pull out the front cap, remove the filter element, and if there is dust inside the housing, clean it with an air gun(make sure that it does not damage the O-rino)
- damage me of might.

 A Install new fiber element on the front cap and insert it into the housing.

 S. Alion the side without number of front cap at the limit mark and push
- It until touching the housing 6. Rotate clockwise with the tool until it stops (align the number at the limit mark)
- When using the filter in positive pressure environment, do not connect the filter behind the solenoid valve, which will cause the filter to withstand frequent shocks? I solenoid valve is long-term frequent on-off

Cautions:

- When connecting the hose, check the arrow indicating the flow direction.
 If reverse connecting, airtightness of the filter element cannot be ensured.
- In one air line, positive and negative pressure should not be used at the same time
 Please make sure not to damage the O-ring during assembling and
 disassembling. And please confirm that there is no air leakage after the filter
- element is replaced 4. The vacuum filter and hose shall not withstand external force such as torsion,
- pull, load, vibration, impact, etc., and external force may cause danger at high positive pressure 5. There is anti-rotating structure at the limit mark. After replacing the filter
- element please confirm the position of the limit mark 6. Please use vacuum filter at rated working pressure

 Compressed air operation may cause danger. Therefore, filter replacement and other maintenance should be operated by a person who has sufficient knowledge and experience in air mechanics while complying with product specifications.







